




Outer dimensions, mounting instructions


Socket




Plugs




Lid




Cover



Pin installation on plug




Base mounting



0.5 Nm < Tightening torque < 0.8 Nm

Flush mounting


The flush mounting kit must be mounted on the socket prior to the installation on the panel.



Tightening torque = 0.5 Nm maxi.



Half-base mounting
Rack mounting

The rack mounting is supplied with 2 additional guiding pins.



0.5 Nm < Tightening torque < 0.8 Nm


TH35 rail mounting




Assembly

Disassembly

Base mounting with KEM-3



Reverse mounting



G32 rail mounting

